

How to install GM XG and GM2 Voices on DGX-670

1. Extract the Voices folder from the **GM, XG, and GM2 Voices (DGX-670).Zip** file onto a USB stick
2. Plug it into the DGX-670
3. Press any VOICE button (such as PIANO & E. PIANO)
4. Tab to USB1
5. Arrow until the Voices folder is highlighted
6. Press Enter

Copy and Paste the Voices folder onto the keyboard memory

1. Choose the File menu item (buttons below screen, column 8, bottom row)
2. Choose the Copy menu item (button column 3)
3. Choose the All menu item (button column 8)
4. Choose the OK menu item (button column 7)
5. Tab to User
6. Choose the Paste menu item (button column 4)
It will display **Now Executing**
7. Unplug USB Stick

Now the GM+XG and GM2 folders will appear in the User tab, and you can use all these voices as normal!

Below is a listing of all these voices.

GM+XG

Bass

AcidBass
AcousticBass
Bass&DistEG
ClaviBass
ClickSynBass
DX Bass
FastResoBass
FingerBass
FingerBass2
FingerDark
FingerSlap
FlangeBass
FretlessBass1
FretlessBass2
FretlessBass3
FretlessBass4
Hammer
JazzRhythm
MellowSyBass
ModulatedBass
ModulrSyBass
MutePickBass
Orbiter
PickBass
PunchThumb
ResonantSlap
RubberBass
SequenceBass
SlapBass1
SlapBass2
SmoothSyBass
SmthFretless
SquareBass
SynthBass1 Dark
SynthBass1
SynthBass2 Dark
SynthBass2
SynthFretless
TechnoBass
VelocitySwiSlap
VXUprghtBass
XWireBass

Brass

AnalogBrass1
AnalogBrass2
AnaVelBrass1
AnaVelBrass2
BrassSect2
BrassSection1
BrightTrumpet
ChoirBrass
FrenchHorn
FrenchHorn2
FrenchHornSolo
HighBrass
HornOrchestr
JumpBrass
MellowBrass
MutedTrumpet
PolyBrass
QuackBrass
ResoSynBrass
SoftBrass
SynthBrass1
SynthBrass2
SynthBrass3
SynthBrass4
Tp&TbSection
Trombone1
Trombone2
Trumpet1
Trumpet2
Tuba1
Tuba2
WarmTrumpet

ChromaticPerc

Balimba
Carillon
Celesta
ChurchBells
Cimbalom
Dulcimer1
Dulcimer2
Glockenspiel
HardVibes
LogDrums
Marimba KSP
Marimba
MusicBox1

MusicBox2
Santur
SineMarimba
TubularBells
Vibraphone KSP
Vibraphone
Xylophone

Ensemble

60'sStrings
70'sStrings
AnalogVoice
ArcoStrings
ChoirAahs1
ChoirAahs2
ChoirStrings
Choral
Impact
Kingdom
LegatoStrngs
MellowChoir
Orchestra1
Orchestra2
OrchestraHit1
OrchestraHit2
ResoStrings
S.SlowStrngs
SlwAtkStrngs
StereoChoir
StereoStrngs
Strings1
Strings2
Strings3
SynStrings1
SynStrings2
SynStrings4
SynStrings5
SynthVoice1
SynthVoice2
TremOrchestra
VelocityStrings
VoiceOohs
WarmStrings

Ethnic

Bagpipe
Banjo
DetunedSitar
Fiddle

Gopichant
Hichiriki
Kalimba
Kanoon
Koto
MutedBanjo
Oud
Pungi
Rabab
Shamisen
Shanai1
Shanai2
Sitar1
Sitar2
Taisho-kin
Tamboura
Tambra

Guitar

12StrGuitar
ChorusGuitar
CleanGuitar
Distortion
FeedbackGuitar1
FeedbackGuitar2
FunkGuitar1
FunkGuitar2
GtrFeedback
GuitarHarmonics1
GuitarHarmonics2
GuitarPinch
JazzAmp
JazzGuitar
JazzMan
Mandolin
MellowGuitar
MutedGuitar
MuteSteelGtr
Nylon&Steel
NylonGuitar1
NylonGuitar2
NylonGuitar3
Overdriven
Steel&Body
SteelGuitar1
SteelGuitar2
Ukulele
VelGtrHarmo

Organ

16+2'2_3Org
60sDrawOrg1
60sDrawOrg2
60sDrawOrg3
70sDrawOrg1
70sDrawOrg2
70sPercOrgan
Accordion Italian
Accordion
CheezyOrgan
ChurchOrgan1
ChurchOrgan2
ChurchOrgan3
DetDrawOrgan
DetPercOrgan
DrawbarOrg2
DrawbarOrg3
DrawbarOrgan1
EvenBarOrg
FastRotary
Harmonica
Harmonica2
LightOrgan
NotreDame
OrganBass
OrganFlute
PercOrgan1
PercOrgan2
PuffOrgan
ReedOrgan
RockOrgan
RotaryOrgan
SlowRotary
TangoAccord1
TangoAccord2
TremoloOrganFlute

Percussive

Agogo
Altair
AnalogTom
AsianBells
Bonang
Castanets
ElectroPerc.
GamelanGongs
GlassPerc.

GranCassa
MelodicTom1
MelodicTom2
RamaCymbal
RealTom
ReverseCymbal
RockTom
SteelDrums
StereoGamlan
SynthDrum
TaikoDrum
ThaiBells
TinkleBell
Woodblock

Piano

60sE.Piano
BrightPiano
BrightPno KSP
ChorusEP1
ChorusEP2
Clavi KSP
Clavi
ClaviWah
DetunedCP80
Dream
DX EP Hard
DX KotoEP
DX Legend
DX PhaseEP
DX+AnalogEP
E.GrandPiano KSP
E.GrandPiano
ElectricPiano1 KSP
ElectricPiano1
ElectricPiano2 KSP
ElectricPiano2
GrandPiano
GrandPno KSP
HardElectricPiano
Harpsi KSP
Harpsichord1
Harpsichord2
Harpsichord3
Honkytonk KSP
Honkytonk
LayeredCP1
LayeredCP2

MellowE.Piano
MellowGrPno
PianoStrings
PierceClavi
PulseClavi
VXfadeE.Piano1
VXfadeE.Piano2

Pipe

BlownBottle
Flute
Ocarina
PanFlute
Piccolo
Recorder
Shakuhachi
Whistle

Reed

AltoSax
BaritoneSax
Bassoon
BreathyTenor
Clarinet
EnglishHorn
HyperAltoSax
Oboe
SaxSection
SoftTenorSax
SopranoSax
TenorSax1
TenorSax2

SoundEffect

Applause
BirdTweet1
BirdTweet2
BreathNoise
Bubble
Burst
CarCrash
CarEngineIgn
CarPassing
CarTiresSqueal
CuttingNoise1
CuttingNoise2
Dog
DoorSlam
DoorSqueak

Explosion
Feed
Firework
FluteKeyClick
FootSteps
Ghost
GtrFretNoise
Gunshot
Heartbeat
Helicopter
Horse
JetPlane
LaserGun
Laugh
MachineGun
Maou
PhoneCall
Punch
RollrCoaster
ScratchCut
ScratchSplit
Scream
Seashore
Shower
Siren
Starship
Stream
StringSlap
Submarine
TelephonRing1
TelephonRing2
Thunder
Train
Wind
WindChime

Strings

Cello
Contrabass
OrchestralHarp
PizzicatoStr
SlwAtkViolin
SlwAtTremStr
SuspenseStr
Timpani
TremoloStrings
Viola
Violin

YangQin
Synth.Effect
AfricanWind
AirBells
Ancestral
Atmosphere
AtmospherePad
BellChoir
BellHarp
BigPan
Brightness
Carib
ChorusBells
ChristmasBel
ClaviPad
ClearBells
Creation
Creeper
Crystal
DigitalBells
EchoBells
Echoes
Echoes2
EchoPan
FantasyBells
Gamelimba
Glisten
GlockenChime
Goblins
GoblinsSynth
HarmoRain
HarpVox
HollwRelease
LoudGlocken
Night
NylonElPiano
NylonHarp
Planet
Popcorn
Prologue
Rain
Reso&Panning
RingPad
Ritual
RoundGlocken
Sci-Fi
Smokey

SoftCrystal
SoundTrack
StarDust
Starz
SynthDrumComp
SynthMallet
SynthPiano
TinyBells
ToHeaven
VibeBells
WarmAtmosphere

Synth.Lead
Bass&Lead
Big&Low
BigFive
BigLead
CalliopeLead
CharangLead
ChiffLead
DigitalSaw
DistortedLd
Dr.Lead
DynamicSaw
Fat&Perky
FifthsLead
HeavySynth
Hollow
LM Square
Mellow
PulseSaw
PureLead
Rubby
SawtoothLead1
SawtoothLead2
SeqAnalog
Shroud
SineLead
SoftWhirl
SoloSine
SquareLead1
SquareLead2
SynthAahs
ThickSaw
VelocityLead
VoiceLead
VoxLead
WaspySynth

WireLead

Synth.Pad

AnalogPad

BowedPad

CCPad

Celestial

ChoirPad

ClickPad

Converge

Fantasy

Glacier

GlassPad

HaloPad

Heaven

HornPad

Itopia

MetallicPad

NewAgePad

PanPad

PolarPad

PolyPad80

PolySynthPad

RotaryStrngs

Shwimmer

SinePad

SoftPad

SquarePad

SweepPad

ThickPad

TinePad

WarmPad

GM2

Bass

AcousticBass
AttackBass
AttackPulse
ClaviBass
FingerBass
FingerSlap
FretlessBass
Hammer
PickBass
ResoSynhBass
RubberBass
SlapBass1
SlapBass2
SynthBass1
SynthBass2
WarmSyBass

Brass

AnaSynBrass1
AnaSynBrass2
BrassSection1
BrassSection2
BrightTrombone
DarkTpSoft
FrenchHorn1
FrenchHorn2
JumpBrass
MutedTrumpet1
MutedTrumpet2
SynthBrass1
SynthBrass2
SynthBrass3
SynthBrass4
Trombone1
Trombone2
Trumpet
Tuba

ChromaticPerc

Carillon
Celesta
ChurchBells
Dulcimer
Glockenspiel
Marimba Wide
Marimba

MusicBox
TubularBells
Vibraphone W
Vibraphone
Xylophone

Drum

AnalogSet.T374.drm
BrushSet.T375.drm
ElectroSet.T267.drm
JazzSet.T267.drm
OrchestraSet.T376.drm
PowerSet.T267.drm
RoomSet.T373.drm
SFX Set.T266.sfx
StandardSet.T373.drm

Ensemble

60'sStrings
6thHit
AnalogVoice
BassHitPlus
ChoirAahs1
ChoirAahs2
EuroHit
Humming
OrchestraHit
Strings1
Strings2
StringsBrass
SynStrings1
SynStrings2
SynStrings3
SynthVoice
VoiceOohs

Ethnic

Bagpipe
Banjo
Fiddle
Kalimba
Koto
Shamisen
Shanai
Sitar1
Sitar2
TaishoKoto

Guitar

12StrGuitar

CleanGuitar
 DetCleanGuitar
 Distortion
 DstRhythmGtr
 FeedbackGtr
 FunkGuitar
 GtrFeedback
 GtrHarmonics
 GuitarPinch
 JazzGuitar
 JazzMan
 Mandolin
 MidToneGtr
 MutedGuitar
 MutedV-SwGtr
 NylonGt KeyOff
 NylonGuitar1
 NylonGuitar2
 Overdriven
 PedlSteelGtr
 Steel&Body
 SteelGuitar
 Ukulele

Organ

Accordion1
 Accordion2
 ChrchOrganOct
 ChurchOrgan
 DetChurchOrgan
 DetDrawOrgan
 DetPercOrgan
 DrawbarOrgan1
 DrawbarOrgan2
 Harmonica
 It60'sOrgan
 PercOrgan
 PercOrgan2
 PuffOrgan
 ReedOrgan
 RockOrgan
 TangoAccord

Percussive

Agogo
 Castanets
 ConcertBD
 ElectricDrum
 MelodicTom1

MelodicTom2
 ReverseCymbal
 RhythmBoxTom
 SteelDrums
 SynthDrum
 TaikoDrum
 TinkleBell
 Woodblock

Piano

60sE.Piano
 BrightPiano
 BrightPno Wide
 Clavi
 DetunedEP1
 DetunedEP2
 E.GrandPiano Wide
 E.GrandPiano
 ElectricPiano1
 ElectricPiano2
 EP1 VeloMix
 EP2 VeloMix
 EPLegend
 EPPHase
 GrandPiano
 GrandPno Dark
 GrandPno Wide
 Harpsi KeyOff
 Harpsi OctMx
 Harpsi Wide
 Harpsichord
 Honkytonk Wide
 Honkytonk
 PulseClavi

Pipe

BlownBottle
 Flute
 Ocarina
 PanFlute
 Piccolo
 Recorder
 Shakuhachi
 Whistle

Reed

AltoSax
 BaritoneSax
 Bassoon

Clarinet
EnglishHorn
Oboe
SopranoSax
TenorSax

SoundEffect

Applause
BirdTweet1
BirdTweet2
BreathNoise
Bubble
BurstNoise
CarCrash
CarEngine
CarPass
CarStop
Dog
Door
DoorCreaking
Explosion
FluteKeyClick
Footsteps
GtrCutNoise
GtrFretNoise
Gunshot
HeartBeat
Helicopter
HorseGallop
Jetplane
Lasergun
Laughing
MachineGun
Punch
Rain
Scratch
Screaming
Seashore
Siren
Starship
Stream
StringSlap
TelephoneRing1
TelephoneRing2
Thunder

Synth.Pad

BowedPad
ChoirPad

Train
Wind
WindChime

Strings

Cello
Contrabass
OrchestralHarp
PizzicatoStr
SlwAtkViolin
Timpani
TremoloStrings
Viola
Violin
YangQin

Synth.Effect

Atmosphere
Brightness
Crystal
EchoBell
Echoes
EchoPan
Goblins
Rain
Sci-Fi
SoundTrack
SynthMallet

Synth.Lead

Bass&Lead
CalliopeLead
CharangLead
ChiffLead
DoublSawLead
FifthsLead
SawPulseLead
SawtoothLead1
SawtoothLead2
SeqAnalog
SineLead
SoftWhirl
SquareLead1
SquareLead2
VoiceLead
WireLead

HaloPad
ItopiaPad

MetallicPad
NewAgePad
PolySynthPad
SinePad
SweepPad
WarmPad